




PANOS R R100/150/200 PLANARRING





R100



R150



R200



DE Die Montage und Inbetriebnahme darf nur von autorisiertem Fachpersonal durchgeführt werden.

EN Installation and commissioning may only be carried out by authorized specialists.

FR L'installation et la mise en service doivent obligatoirement être effectuées par des techniciens.

IT Montaggio ed avviamento devono essere eseguiti solo da personale specializzato.

NL De montage en inbedrijfstelling mogen enkel door erkend vakpersoneel worden uitgevoerd.

SE Monteringen och idrifttagandet får endast företas av auktoriserad fackpersonal.


FI Asennuksen ja käyttöönoton saa tehdä vain auktorisoitu ammattihenkilöstö.

ES El montaje y la puesta en marcha sólo puede ser realizado por personal especializado autorizado.

CN 组装和调试只能由授权的专业人员进行。


AR لا يجوز إجراء التجميع والتشغيل إلا من قبل موظف مختصين معتمدين

1




PANOS INF...	X (mm)	T (mm)
R100	100	
R150	150	1-25
R200	200	1-25

2




3




**WALLWASHER
(WW) 100/150/200**

R150/200




R100


4



5



6



7

